













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod














A	B	C (mm)		D
1	M141-001A	1943	296	2/2
2	M141-101A	1932	380	2/2
3	M141-102A	1932	380	2/2
4	M141-201	600	400	1/2
5	M141-202	600	380	1/2
6	M141-301	566	345	1/2
7	M141-302	567	360	1/2
8	M141-9901	1942	577	2/2



1 








Pflegehinweis!

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!



7

